## BORE GAGE FOR BARRIER INSIDE BORE










- Measure diameter of bores with barrier inside
- Optional accessory:
  - 0.01mm graduation dial indicators
  - Setting ring (code **6312**)





2348-210

(mm)

Code	Range ØD	Diameter of barrier Ød	Travel of measuring tip	Accuracy (without dial indicator)	Measuring force
2348-210*	40-210mm	<d-14 (less="" 50mm)*<="" th="" than=""><th>1.6</th><th>0.018</th><th>2N</th></d-14>	1.6	0.018	2N

<sup>\*</sup>For example:

When measuring size ØD is 40mm, D-14=26mm, so the diameter of barrier should be less than 26mm. When measuring size ØD is 70mm, D-14=56mm, however it should be less than 50mm, so the diameter of barrier should be less than 50mm