


Spare parts for digital protractor 2172



Part NO.	Code	Description
1	SP-SCREW-2172	Screw for 2172-360A
2	SP-BATTERY COVER-2172-1	Battery cover for 2172-360A
3	SP-CIRCUIT BOARD-2172	Circuit board for 2172-360A
4	SP-DISPLAY-2172	Display screen(include conductive rubber) for 2172